

720 - GRILL CLEANER SPRAY

GRILL CLEANER is special formulated for cleaning of charcoal- and gas grills. Grill Cleaner efficiently dissolves grease and burnt-in food residues on inner sides of barbeque and grids and eases the cleaning.

Instructions

Close the warm grill and let cool down to approx. 50°C, or when the grid is just touchable by hand. Spray grill cleaner on the surface in an even thin layer. After 10 min. of reaction time, the surface is cleaned with a scouring sponge and clean water. Wash again carefully with clean water. Heavy contaminated areas may require a second treatment. May attack linoleum, aluminium and painted surfaces.

Declaration

Contains: <15% Sodium-hydroxide, <15% non- ionic surfactants. Also contains: water and isopropyl alcohol.

DANGER: Corrosive: Causes severe skin burns and eye damage. Do not breathe spray. Wash skin thoroughly after handling. Wear suitable gloves and eye/face protection. Keep out of the reach of children.

IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.

IF ON SKIN: Take off immediately all contaminated clothing. Rinse skin with water.

IF INHALED: Remove person to fresh air and keep comfortable for breathing.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor.



Conditioning

500ml (12 units/box)

If you have any questions, please contact our Technical Department on: +45 4817 6970